

CHENBRO



User's Manual

SK23502 3-to-5 SCSI HDD Storage Kit

Version 1.0

May / 26 / 2008



Copyright

Copyright © 2006 CHENBRO Micom Co., Ltd.. All rights reserved.

Unless otherwise indicated, all materials in this manual are copyrighted by CHENBRO Micom Co., Ltd.. All rights reserved. No part of this manual, either text or image may be used for any purpose other than internal use within purchasing company. Therefore, reproduction, modification in any form or by any means, electronic, mechanical or otherwise, for reasons other than internal use, is strictly prohibited without prior written permission.

CHENBRO Micom Co., Ltd. reserves the right to make improvement and modification to the products indicated in this manual at any time. Specifications are therefore subject to change without prior notice.

Information provided in this manual is intended to be accurate and reliable. However, CHENBRO Micom Co., Ltd., assumes no responsibility for its use, nor for any infringements upon the rights of third parties, which may result from its use.

Technical Support

CHENBRO works hard to offer our customers maximum performance from our chassis. But in case you have any problem with our product you can find supports from the following resources.

Web Support

Detail information of our products is in our website. You can find technical updates, installation guides, FAQs, Technical specifications and more. Our web address is: www.chenbro.com.

Email Support

You can also fill out the technical support from at our <u>Technical Support</u> page. You technical issue inquiries will be sent directly to our support professionals.

Phone Support

You can also contact CHENBRO HQ or branch office for immediate support; their contact Information is as following:

CHENBRO HQ CHENBRO Europe B.V. CHENBRO Micom (USA) Inc.

Tel: 886-2-8226-5500 Tel: 31-40-295-2045 Tel: 1-909-947-3200 Fax: 886-2-8226-5423 Fax: 31-40-295-2044 Fax: 1-909-947-4300



Contents

Copyright	2
Technical Support	2
Contents	3
Revision History	4
Safety Information	5
Conventions Used in this Manual	5
Getting Start with the SK23502 Storage Kit	6
Unpacking and Checking the Contents	6
Technical Specifications	6
Compatible CHENBRO Chassis	6
Introduction	7
Functional Specification	7
General	7
Host / Drive / Power Interfaces	7
Monitoring Function	7
Mechanical Dimension	8
Components Description	9
Front View	9
Rear View	10
Multifunctional Switch Definition	11
Installation Procedures	12
Hot-swap HDD Assembly	12
Accessing the exhaust fan	14
Accessing backplane assembly	15
Relative Part Number List	17



Revision History

Date	Modifications
May / 26 / 2008	First Release



Safety Information

- Read the installation instructions before connecting SK23502 to the power source.
- Only trained and qualified personnel should be allowed to install, replace or service this equipment.
- Never install this product in a wet environment.
- Position system cables and power cables carefully; route system cable and the power cable and plug so
 that they cannot be stepped on or tripped over. Be sure that nothing rests on your system components'
 cables or power cable.

Conventions Used in this Manual

The following conventions are used in this manual.



Note Icon:

Provides more information on the current topic.



Important Icon:

Provides important information on the current topic that must not be overlooked.



Getting Start with the SK23502 Storage Kit

Thank you for purchasing SK23502! This section covers unpacking and identifying components.

Unpacking and Checking the Contents

The complete SK23502 package includes the following items:

Item Description	
SK23502 Storage Cage	1
Hot-swap 3.5" Hard Disk Drive (HDD) Tray	5
USB Cable, 750mm	
SCSI Cable, 500mm	1
SCSI Terminator	
Screw: #6-32 (6mm) for tray and HDD assembling	
Screw: M3 (6mm) for Storage Cage and chassis assembling	12

Technical Specifications

Occupancy	3 x 5.25" Drive Bays
Capacity	5 x Ultra320 SCSI HDDs
Cooling Subsystem	1 x 80mm (T32mm) Exhaust Fan
	Fan Fail Detection LED and Alarm
System Monitoring	Overheat LED and Alarm
	HDD Failure LED and Alarm
Front Access	Two USB ports on the front panel
Dimensions (WxHxD)	146 x 127.3 x 218.2 (mm)
	5.75 x 5.01 x 8.59 (inch)
Weight (Fan included)	2.2 kg

Compatible CHENBRO Chassis

- RM31300 / RM41100 / RM41500 / RM42200
- SR105 / SR107 / SR108 / SR209



Introduction

The CHENBRO SK23502 can house five 3.5" HDDs in a three 5.25" bays converter (Depth of 9.5" recommended). The ability for conversion allows existing servers to perform the maximum HDD density while keeping the flexibility. All in all, SK23502 is the best solution as value added feature and performance.

Functional Specification

General

- Support Ultra320 SCSI SCA (80pin) interface
- Compatible with 3.5" Ultra320 SCSI drive
- SCSI ID is based on "group" and configured by a DIP switch without ID conflict check
- 2-digit DIP switch to control HDD spin up: AUTO, DELAY, and COMMAND
- Individual activity signals for each HDD


Host / Drive / Power Interfaces


- 5x Ultra-320 SCSI HDDs on backplane with 80-pin SCA2 connectors for internal connection
- 2x HDCI SCSI in / out 68-pin connectors for backplane cascading, external device and terminator.
- 2x USB access ports
- 2 x DC power connectors in 4-pin D-type


Monitoring Function

- 1x Fan 3P3C jack with speed monitoring
- Fan monitoring can be disabled
- 2x temperature sensors for HDD overheat monitoring
- Overheat alarm temperature is selectable : 55℃ or 65℃
- Support one buzzer for audible alarm, three fail LED output for fan / overheat / HDD failure events, one alarm mute button for disabling audible alarm

Mechanical Dimension








unit: mm

CHENBRO



Components Description






	Device	Function	
1	USB jack	Front USB port	
2	Alarm mute button	Click to stop the system failure alarm	
3	Overheat Warning LED		
4	Fan failure LED	Red LED On - Fan failure	
5	Reserved LED	Reserved	
6	3.5" HDD Hot-swap Tray	Refer to Page 13	
7	HDD activity LED	Green LED On - HDD active	
8	HDD Power LED	Blue LED On - HDD Power On	

Rear View





	Devices	Function		
1	SCSI jack	SCSI Out jack		
2	SCSI jack	SCSI In jack		
3	Power jacks	4P jack for power input		
4	USB jack	USB interface between front bezel & motherboard		
5	Multifunctional Switch	Refer to Page 11		
6	Fan jack	Connecting 80mm fan		

Multifunctional Switch Definition

[DIP1/DIP2]: HDD Spin-up option

DIP1	DIP2	Function	Remark
Off	Off	Spin up when power is apply	Default
Off	On	Spin up on start command	
On	Off	Spin up after delay	
On	On	Reserved	



CHENBRO

SW1 Default Setting

[DIP3]: HDD ID setting

DIP3	HDD ID (HDD1 – HDD5)	Remark
On	8 ~ 12	
Off	0 ~ 4	Default

[DIP4]: Fan1 monitoring alarm setting

DIP4	Fan1	Remark
On	Alarm Enable	Default
Off	Alarm Disable	

[DIP5]: Temperature monitoring alarm setting

DIP5	Temperature	Remark
On	65℃	Default
Off	55℃	

[DIP6]: Reserved




Installation Procedures


The following is the installation procedures for HDD and rear cover assembly.

Hot-swap HDD Assembly

a. Push the blue latch on HDD tray and pull it out from the cage




b. Attach HDD with four screws per tray






c. Insert HDD tray to the cage







Accessing the exhaust fan

- a. Unplug the fan power connector
- b. Push the tab on the right side (where have "PUSH" mark on the rear cover)



c. Pull out the fan holder







CHENBRO

Accessing backplane assembly


a. After removing the rear exhaust fan, unscrew four screws to remove the rear cover






CHENBRO

b. Remove two screws on the backplane







Relative Part Number List

CHENBRO Part Number	Description	Unit	Remark
80H035335-001	LED Board	pcs	
80H105235-002	SK23502 SCSI Backplane	pcs	
26H073214-003	SCSI Cable, 500mm	pcs	
26H033219-002	USB Cable, 750mm	pcs	
31H040000-006	SCSI Terminator	pcs	
30H080032-102	80mm (Thickness 32mm), Ball Bearing Fan	pcs	
83H555335-011	Hot-swap HDD Tray	pcs	